

## SWING HINGE STYLE BRONZE SERVICE SADDLES ON O.D. CONTROLLED PLASTIC PIPE

Installation Instructions

## IMPORTANT: ALWAYS FOLLOW PIPE MANUFACTURERS' RECOMMENDATIONS FOR STYLE OF SADDLE SUITABLE FOR USE ON SIZE AND TYPE OF PIPE INVOLVED.

- **Step 1** To ensure a proper seal, clean and smooth the pipe in the area where the clamp is to fit, especially where the O-ring is clamped to the pipe.
- **Step 2** Disengage screw from lower half of saddle (it will be retained on saddle by plastic washer).
- **Step 3** Open hinge and place saddle on pipe in final position.
- **Step 4** Engage and tighten screw to 72 in-lbs. torque minimum (9 lbs. on 8" wrench); 104 in-lbs. maximum (13 lbs. on 8" wrench).
- **NOTE** Use suitable sealant or joint-sealing tape on inlet threads.

## Phone: (800) 423-1323

By deviating from the above listed instructions, you will void any product warranty and release Mueller Water Products Inc. and its affiliated entities from any and all liability associated with the installation or use of this product. For details on the product's warranty, terms, and conditions, please visit www.muellerwp.com.

© 2020 Mueller Co., LLC. All Rights Reserved. The trademarks, logos and service marks displayed in this document are the property of Mueller Co., LLC., its affiliates or other third parties.

